

Belzona 1291

FN10023 (ES-METAL)



INSTRUCTIONS FOR USE

1. TO ENSURE AN EFFECTIVE MOLECULAR WELD

APPLY ONLY TO CLEAN, FIRM, DRY AND WELL ROUGHENED SURFACES.

- Wipe away excess leaking material. Use a dry rag in the case of water, and a rag soaked in **Belzona® 9111** (Cleaner/Degreaser) or any other effective cleaner which does not leave a residue e.g. methyl ethyl ketone (MEK) for other contamination.
- Roughen surfaces by blast cleaning, deeply scoring or grinding.
- Apply only to stabilized cracks. Vee-out all cracks using a rotary file.
- Finally degrease again. Use clean rags to avoid spreading contamination.

2. COMBINING THE REACTIVE COMPONENTS

Cut off the required amount of material and knead in gloved hands to a uniform grey colour. Mixing is aided by storing the material between 68 - 77°F (20 - 25°C).

WORKING LIFE

From commencement of mixing, **Belzona® 1291** should be used within approximately 4 minutes.

3. APPLYING BELZONA® 1291

Use **Belzona® 1291** to seal live leaks. Force the mixed material into cracks and holes and apply pressure until the material has hardened.

This is best achieved using the **Belzona®** Tourniquet provided. Peel away the Velcro fastener and unroll the rubber strip. Whilst pressing the inward curving end of the rubber strip onto the **Belzona® 1291**, stretch the Tourniquet tightly around the repair ensuring each wrap overlaps approximately half way over the previous wrap. Secure with the Velcro end.

After approximately 1 hour remove the Tourniquet and apply **Belzona® 1111, 1121 or 1221** to secure the repair.

Spread the **Belzona®** onto the **Belzona® 9341** (Reinforcement Tape). Apply the bandage to the area to be repaired with the coated side adjacent to the substrate.

Press down firmly to fill all cracks, remove entrapped air, and ensure maximum contact with the surface.

In the case of pipes, wrap tightly round several times so that the **Belzona®** is forced through to the outside of the **Belzona® 9341**.

4. CLEANING

Mixing tools should be cleaned immediately after use with **Belzona® 9111** or any other effective solvent e.g. Methyl ethyl ketone (MEK), acetone or cellulose thinners.

5. APPLICATION GUIDELINES

- For low pressure application (below 7 bar/100psi/7kg/cm²) repairs using Reinforcement Tape are satisfactory.
- For higher pressures and extra security a metal reinforcement patch fabricated from similar material to the substrate should be incorporated into the repair.

The patch should be profiled to follow substrate and should extend at least 1 inch (2.5 cm) beyond the damaged area.

Please telephone or fax **Belzona®** TKHL for further information.

HEALTH & SAFETY INFORMATION

Please read and make sure you understand the relevant Safety Data Sheets.

The technical data contained herein is based on the results of long term tests carried out in our laboratories and to the best of our knowledge is true and accurate on the date of publication. It is however subject to change without prior notice and the user should contact Belzona to verify the technical data is correct before specifying or ordering. No guarantee of accuracy is given or implied. We assume no responsibility for rates of coverage, performance or injury resulting from use. Liability, if any, is limited to the replacement of products. No other warranty or guarantee of any kind is made by Belzona, express or implied, whether statutory, by operation of law or otherwise, including merchantability or fitness for a particular purpose.

Nothing in the foregoing statement shall exclude or limit any liability of Belzona to the extent such liability cannot by law be excluded or limited.

Copyright © 2015 Belzona International Limited. Belzona® is a registered trademark.

*Belzona products are
manufactured under an
ISO 9001 Registered
Quality Management System*

